

Item Number
RAM-VB-136

RAM No-Drill™ Seat Bases

National Products, Inc.

Vehicle base for the Chevrolet Astro Van (2000-Newer)

SPECIFICATIONS

Placement

Attaches between seat frame and floor board. Uses front and rear, inside seat studs.

Drilling Required

No - uses existing seat bolts

Seat Configuration

Bucket

Construction/Finish

Steel/Black Powdercoat

Pole or Pedestal

Included on Base

Weight

6.1 lbs.

Dimensions

A = 14.57", B = 7.25", C = 17.75"

Hole Center = 12.625"

Features

Installs in minutes with no drilling required

Misc.

Rock solid construction
Lifetime warranty

National Products, Inc.
Phone: 206-763-8361
Fax: 206-763-9615
Address: 1205 S Orr St
Seattle, WA 98108
Website: www.ram-mount.com
Email: staff@ram-mount.com



Shown In Use



RAM-VB-136



Item Number
RAM-VB-136

RAM No-Drill™ Seat Bases
National Products, Inc.

**Vehicle base for the
Chevrolet Astro Van (2000-Newer)**

INSTALLATION INSTRUCTIONS

1. Remove the two nuts that hold the seat rail track to the seat frame. These are located on the lefthand side, underneath the seat. Remove metal framework of chair skirt
2. Place the custom metal base over the mounting bolts that hold the seat track to the seat frame, tube facing up.
3. While holding the metal base in place, replace metal skirt frame and put the nuts back onto the seat track bolts and tighten.

National Products, Inc.
Phone: 206-763-8361
Fax: 206-763-9615
Address: 1205 S Orr St
Seattle, WA 98108
Website: www.ram-mount.com
Email: staff@ram-mount.com

